

Aram

Nendo



Uso y mantenimiento general. Care and general use

Para una óptima conservación de los muebles se recomienda limpiar periódicamente todos los elementos, como se indica en las instrucciones de limpieza, evitando así la acumulación de suciedad e impurezas.

En ambientes marinos o con elevada humedad (como SPA's, Beach Clubs,...) es recomendable extremar las precauciones de limpieza, especialmente en las colecciones con componentes de acero inoxidable.

Los muebles son resistentes a ralladuras e impactos bajo condiciones normales de uso. La exposición prolongada a temperaturas superiores a 60°C [140°F] puede causar daños en los materiales con los que están fabricados.

Con el fin de conservar el producto a lo largo del tiempo le recomendamos que:

- No usar limpiadoras de alta presión ni agua fuera del rango de 10-40 grados centígrados. En caso de utilizar cualquier otro producto o sistema de limpieza, el producto no quedará cubierto por la garantía.
- No arrastren el producto, al moverlo levántelo para no estropear las partes que apoyan en el suelo.
- Protejan el producto de los golpes y de contactos con objetos puntiagudos y cortantes, así como los líquidos o productos de limpieza que contengan agentes corrosivos.
- Aténgase a los consejos de mantenimiento que se dan en la correspondiente sección de la documentación adjunto al producto.

¡Advertencia!

En Gandia Blasco, nos esforzamos por ofrecer productos de alta calidad y durabilidad. Sin embargo, es crucial tener en cuenta que un uso descuidado o inapropiado de los tops de nuestras mesas puede ocasionar ralladuras o daños en los materiales, como aluminio lacado, aluminio anodizado, polietileno, madera, fenólico, dekton, mdi y mvi.

Para garantizar la óptima conservación de los tops de las mesas, recomendamos tratarlos con sumo cuidado y seguir estrictamente las instrucciones de mantenimiento proporcionadas. Es importante evitar el uso de objetos afilados, abrasivos o duros que puedan rayar la superficie. Asimismo, se debe evitar arrastrar objetos sobre el top de la mesa, ya que esto también puede causar daños.

Por favor, tenga en cuenta que nuestra garantía no cubre daños ocasionados por un uso inadecuado ni las ralladuras derivadas del desgaste cotidiano.

For an optimal conservation of the furniture, we recommend to clean all elements regularly, following the cleaning instructions, thus avoiding any accumulation of dirt and impurities on the furniture.

Nearby the sea or in atmospheres with a high humidity level (like SPAs, Beach Clubs, ...) we recommend to take additional cleaning precautions, specially in collections with stainless steel components.

The furniture is resistant to scratches and impacts under normal use conditions. Prolonged exposure to temperatures above 140°F (60°C) may harm the materials of which they are made.

In order to preserve the product over time we recommend:

- Do not use high-pressure cleaners or water outside the range of 10 to 40 degrees Celsius. If any other product or cleaning system is used, the product will no longer be covered by the warranty.
- Do not drag the product. When moving it, lift it so as not to scratch the parts that rest on the floor.
- Protect the product from bumps and from contact with pointy or sharp objects, as well as liquids or cleaning products with corrosive agents.
- Follow the maintenance guidelines provided in the corresponding section of the document attached to the product.

Warning!

At Gandia Blasco, we strive to offer products of high quality and durability. However, it is crucial to take into account that careless or inappropriate use of our table tops can cause scratches or damage to the materials, such as lacquered aluminum, anodized aluminum, polyethylene, wood, phenolic, dekton, MDi and MVi.

To ensure optimal preservation of the table tops, we recommend treating them with the utmost care and strictly following the maintenance instructions provided. It is important to avoid using sharp, abrasive or hard objects that could scratch the surface. Also, avoid dragging objects across the top of the table, as this can also cause damage.

Please note that our warranty does not cover damage caused by improper use or scratches from everyday wear and tear.

Limpieza. Cleaning

Acero inoxidable termolacado. Powder-coated stainless steel

Limpiar con agua y jabón neutro con un trapo suave. No utilizar productos de limpieza que contengan disolventes ni blanqueantes (lejía). No utilizar estropajos ni cepillos de metal.

Clean with water and neutral soap with a soft cloth. Do not use products containing solvents or bleaching agents. Do not use scourers or metal brushes.