

For an optimal conservation of the furniture, we recommend to clean all elements regularly, following the cleaning instructions, thus avoiding any accumulation of dirt and impurities on the furniture and the accumulation of water on the seats.

Nearby the sea or in atmospheres with a high humidity level (like SPAs, Beach Clubs, ...) we recommend to take additional cleaning precautions, specially in collections with stainless steel components. The furniture is resistant to scratches and impacts under normal use conditions. Prolonged exposure to temperatures above 140°F (60°C) may harm the materials of which they are made.

In order to preserve the product over time we recommend:

- Do not use high-pressure cleaners or water outside the range of 10 to 40 degrees Celsius. If any other product or cleaning system is used, the product will no longer be covered by the warranty.
- Do not jump and do not sit on protruding parts, or on the backs or armrests.
- Do not drag the product. When moving it, lift it so as not to scratch the parts that rest on the floor.
- Protect the product from bumps and from contact with pointy or sharp objects, as well as liquids or cleaning products with corrosive agents.
- Follow the maintenance guidelines provided in the corresponding section of the document attached to the product.

Warning!

At Gandia Blasco, we strive to offer products of high quality and durability. However, it is crucial to take into account that careless or inappropriate use of our table tops can cause scratches or damage to the materials, such as lacquered aluminum, anodized aluminum, polyethylene, wood, phenolic, porcelain, concrete and MVi.

To ensure optimal preservation of the table tops, we recommend treating them with the utmost care and strictly following the maintenance instructions provided. It is important to avoid using sharp, abrasive or hard objects that could scratch the surface. Also, avoid dragging objects across the top of the table, as this can also cause damage.

Please note that our warranty does not cover damage caused by improper use or scratches from everyday wear and tear.

Limpieza. Cleaning

Aluminio termolacado. Powder-coated aluminium

Limpiar con agua y jabón neutro con un trapo suave. No utilizar productos de limpieza que contengan disolventes ni blanqueantes (lejía). No utilizar estropajos ni cepillos de metal.

Clean with water and neutral soap with a soft cloth. Do not use products containing solvents or bleaching agents. Do not use scourers or metal brushes.

Cuerda poliéster. Polyester rope

Limpiar con agua y jabón neutro con un trapo suave. No utilizar productos de limpieza que contengan disolventes ni blanqueantes (lejía). No utilizar estropajos ni cepillos de metal.

Clean with water and neutral soap with a soft cloth. Do not use products containing solvents or bleaching agents. Do not use scourers or metal brushes.